Miniconda or Anaconda Installation

請參考官方網站。

https://www.anaconda.com/

Download the latest version of Miniconda or Anaconda

可以安裝最新版,最新版搭配的是最新版的 Python 3.9

Anaconda 版本資訊

https://repo.anaconda.com/archive/

Download the latest version of Miniconda

Miniconda 版本資訊

https://repo.anaconda.com/miniconda/


下載最新版本即可!

Windows 10 環境下安裝安裝 Anaconda 或 Miniconda

安裝 Anaconda 或 Miniconda

請安裝在內定目錄。

其餘步驟都用 yes 即可。



重新進入終端機就可以了!

Mac

安裝方式(與 Linux 安裝方式類似)

https://docs.conda.io/projects/conda/en/latest/user-guide/install/macos.html

到 Terminal 使用 wget 命令下載
wget https://repo.anaconda.com/miniconda/Miniconda3-latest-MacOSX-x86_64.sh - O ~/miniconda.sh

安裝,全部 yes 就可!

bash ~/miniconda.sh

重新進入終端機就可以了!

Apple Mac M1 users may follow the following installation steps. https://www.youtube.com/watch?v=2kNj5oBpfyY Linux
To install Miniconda on Ubuntu 20.04 from command line, it only takes 3 steps

To install Miniconda on Ubuntu 20.04 from command line, it only takes 3 steps excluding creating and activating a conda environment.

1. Download the latest shell script

 $wget\ https://repo.anaconda.com/miniconda/Miniconda3-latest-Linux-x86_64.sh$

2. Make the miniconda installation script executable

chmod +x Miniconda3-latest-Linux-x86_64.sh

3. Run miniconda installation script

./Miniconda3-latest-Linux-x86_64.sh

4. Create and activate an conda environment

To create a conda environment, run conda create -n newenv

You can also create the environment from a file like environment.yml, you can use use the conda env create -f command: conda env create -f environment.yml. The environment name will be the directory name.

重新進入終端機就可以了!

Updating Anaconda or Miniconda

- 1. Open a terminal window.
- 2. Run conda update conda.

Uninstalling Anaconda or Miniconda

- 1. Open a terminal window.
- 2. Remove the entire Miniconda install directory with:

4

Create a virtual environment

寫 Python 程式的人都要會用虛擬環境。

不會使用虛擬環境的人, Python 功力一定是不怎麼樣!



```
Anaconda Prompt (miniconda3)

(base) C:\Users\clhuang>
```

● 看看有那些虛擬環境

conda env list

• Create a virtual environment:

conda create -n ai23 python=3.8

因為我們會用 Python 3.8,因此,我們必須建立自己的 Python 3.8 虛擬環境。 ...因為 Python 版本太新, Tensorflow 還不能支援,許多套件尚未更新。

```
×
  Anaconda Prompt (miniconda3) - conda create -n ai23 python=3.8
 (base) C:\Users\clhuang>conda create -n ai23 python=3.8
Collecting package metadata (current_repodata.json): done
Solving environment: done
   => WARNING: A newer version of conda exists. <=
current version: 4.10.3
latest version: 4.11.0
Please update conda by running
        $ conda update -n base -c defaults conda
## Package Plan ##
    environment location: C:\Users\clhuang\miniconda3\envs\ai23
    added / updated specs:
- python=3.8
The following NEW packages will be INSTALLED:
                                             pkgs/main/win-64::ca-certificates-2021.10.26-haa95532_4
pkgs/main/win-64::certifi-2021.10.8-py38haa95532_2
pkgs/main/win-64::openssl-1.1.1m-h2bbff1b_0
pkgs/main/win-64::pip-21.2.2-py38haa95532_0
pkgs/main/win-64::python-3.8.12-h6244533_0
pkgs/main/win-64::setuptools-58.0.4-py38haa95532_0
pkgs/main/win-64::sqlite-3.37.0-h2bbff1b_0
pkgs/main/win-64::vc-14.2-h2lff451_1
pkgs/main/win-64::vs2015_runtime-14.27.29016-h5e58377_2
pkgs/main/noarch::wheel-0.37.1-pyhd3eb1b0_0
pkgs/main/win-64::wincertstore-0.2-py38haa95532_2
    ca-certificates
    certifi
openssl
   pip
python
setuptools
sqlite
    vc
vs2015_runtime
    wheel
    wincertstore
  roceed ([y]/n)?
```

conda create -n my env (python 不指定版本則為 default)

```
Anaconda Prompt (miniconda3)

done

# To activate this environment, use

# $ conda activate my_env

# To deactivate an active environment, use

# $ conda deactivate

(base) C:\Users\clhuang>__
```

Activate and deactivate an environment

• To activate this environment and to deactivate this environment, use:

Linux:

source activate my_env source deactivate

Windows:

activate my_env
or
conda activate my_env

deactivate

• List all existing virtual environments:

8

conda env list or conda info --envs

Remove an environment

To remove an environment, in your Terminal window or an Anaconda Prompt, run: 刪除虛擬環境

\$ conda env remove -n <environment>

How to run Jupyter notebook(執行)?

Run it from the Start Menu

Run it from the terminal

- (1) Get into the terminal
- (2)Activate your virtual environment

conda activate ai23

(3) Execute jupyter notebook with your working directory c:/users

jupyter lab c:/users

jupyter notebook c:/users

(指定你的工作目錄為 c:/users,若沒有指定則為預設目錄,或是當前目錄)

or enter your working directory first, then run jupyter notebook

cd c:/users jupyter notebook

9

Uninstall anaconda

解除安裝

conda install anaconda-clean anaconda-clean -yes


Linux


rm -rf ~/anaconda3 (for Linux)


Add Anaconda to Windows 10 Path (路徑設定)

Add anaconda to your PATH environment variable

你若在安裝時未勾選加入 PATH 路徑,則你必須設定永久路徑。 方式是在環境變數中,設定系統變數或是使用者變數:







Miniconda for advanced users (進階使用者)

只有 conda 管理工具,完全沒有安裝其他套件,進階使用者可以使用

Miniconda is a free minimal installer for conda. It is a small, bootstrap version of Anaconda that includes only conda, Python, the packages they depend on, and a small number of other useful packages, including pip, zlib and a few others. Use the conda install command to install 720+ additional conda packages from the Anaconda repository.

Anaconda or Miniconda?

Choose Anaconda if you:

Are new to conda or Python.

 Like the convenience of having Python and over 1,500 scientific packages automatically installed at once.

- Have the time and disk space---a few minutes and 3 GB.
- Do not want to individually install each of the packages you want to use.

Choose Miniconda if you:

- Do not mind installing each of the packages you want to use individually.
- Do not have time or disk space to install over 1,500 packages at once.
- Want fast access to Python and the conda commands and you wish to sort out the other programs later.

Download the most recent version of Miniconda

https://repo.anaconda.com/miniconda/


Windows 10: 直接下載安裝即可。

Linux 環境下:

\$wget https://repo.anaconda.com/miniconda/Miniconda3-latest-Linux-x86_64.sh \$bash Miniconda3-latest-Linux-x86_64.sh

安裝 miniconda 完畢占用: 383MB 安裝所有的 AI 套件完畢: 2.37 GB Miniconda installer archive

Filename	Size	Last Modified	MD5
Miniconda2-latest-Linux-ppc64le.sh	51.9M	2020-06-16 14:57:51	120b300120b1362831f2075cc0bd452f
Miniconda2-latest-Linux-x86_64.sh	48.7M	2020-06-16 14:57:45	19ce7d0039ab349914d928e7f32b1c1b
Miniconda2-latest-MacOSX-x86_64.pkg	48.4M	2020-06-16 14:56:46	b6a7cbcc444094d8c533cc0e579c81b9
Miniconda2-latest-MacOSX-x86_64.sh	40.3M	2020-06-16 14:57:58	14e2d294decc5a48a449b588f5819c10
Miniconda2-latest-Windows-x86.exe	47.7M	2020-06-16 14:57:49	54863d2fae6d348b2a91bd1f80c0f4b2
Miniconda2-latest-Windows-x86_64.exe	54.1M	2020-06-16 14:57:46	93a92dc93eb306210a5076b32baea74f
Miniconda2-py27_4.8.3-Linux-ppc64le.sh	51.9M	2020-06-16 14:57:51	120b300120b1362831f2075cc0bd452f
Miniconda2-py27_4.8.3-Linux-x86_64.sh	48.7M	2020-06-16 14:57:45	19ce7d0039ab349914d928e7f32b1c1b
Miniconda2-py27_4.8.3-MacOSX-x86_64.pkg	48.4M	2020-06-16 14:56:46	b6a7cbcc444094d8c533cc0e579c81b9
Miniconda2-py27_4.8.3-MacOSX-x86_64.sh	40.3M	2020-06-16 14:57:58	14e2d294decc5a48a449b588f5819c10
Miniconda2-py27_4.8.3-Windows-x86.exe	47.7M	2020-06-16 14:57:49	54863d2fae6d348b2a91bd1f80c0f4b2
Miniconda2-py27_4.8.3-Windows-x86_64.exe	54.1M	2020-06-16 14:57:46	93a92dc93eb306210a5076b32baea74f
Miniconda3-latest-Linux-ppc64le.sh	92.1M	2020-06-16 14:57:50	a48a5db8c22c47cea7b04af2c3af2a1f
Miniconda3-latest-Linux-x86_64.sh	88.7M	2020-06-16 14:57:56	d63adf39f2c220950a063e0529d4ff74
Miniconda3-latest-MacOSX-x86_64.pkg	61.3M	2020-06-16 14:56:45	8742e44539dcf8002494c7728edff2c5
Miniconda3-latest-MacOSX-x86_64.sh	53.2M	2020-06-16 14:57:53	3fe6d972d40ee60f2e8496cf943ad852
Miniconda3-latest-Windows-x86.exe	49.6M	2020-06-16 14:57:54	99e867dc54d5b3234ab37f29b6344311
Miniconda3-latest-Windows-x86_64.exe	55.7M	2020-06-16 14:57:53	b646dafdea2816cc3526f20a4410c824
Miniconda3-py37_4.8.3-Linux-ppc64le.sh	88.1M	2020-06-16 14:57:45	ae06d853a09764d86e400cd797c2e922
Miniconda3-py37_4.8.3-Linux-x86_64.sh	84.8M	2020-06-16 14:57:55	751786b92c00b1aeae3f017b781018df
Miniconda3-py37_4.8.3-MacOSX-x86_64.pkg	60.4M	2020-06-16 14:56:44	99fdf12ca2a6ab6653cee27792e30e69
Miniconda3-py37_4.8.3-MacOSX-x86_64.sh	52.3M	2020-06-16 14:57:52	d1754f1e192e078b4d207a8b2e5607b0
Miniconda3-py37_4.8.3-Windows-x86.exe	48.3M	2020-06-16 14:57:48	f59e7e24a9994f6a3cd0bba905c5f2c0
Miniconda3-py37_4.8.3-Windows-x86_64.exe	54.6M	2020-06-16 14:57:48	447d4071a03dde17d880eaaf5fc961c9
Miniconda3-py38_4.8.3-Linux-ppc64le.sh	92.1M	2020-06-16 14:57:50	a48a5db8c22c47cea7b04af2c3af2a1f
Miniconda3-py38_4.8.3-Linux-x86_64.sh	88.7M	2020-06-16 14:57:56	d63adf39f2c220950a063e0529d4ff74
Miniconda3-py38_4.8.3-MacOSX-x86_64.pkg	61.3M	2020-06-16 14:56:45	8742e44539dcf8002494c7728edff2c5
Miniconda3-py38_4.8.3-MacOSX-x86_64.sh	53.2M	2020-06-16 14:57:53	3fe6d972d40ee60f2e8496cf943ad852
Miniconda3-py38_4.8.3-Windows-x86.exe	49.6M	2020-06-16 14:57:54	99e867dc54d5b3234ab37f29b6344311
Miniconda3-py38_4.8.3-Windows-x86_64.exe	55.7M	2020-06-16 14:57:53	b646dafdea2816cc3526f20a4410c824
Miniconda3-py37_4.8.2-Linux-ppc64le.sh	50.1M	2020-03-11 10:37:04	e50662a93f3f5e56ef2d3fdfaf2f8e91
Miniconda3-py37_4.8.2-Linux-x86_64.sh	81.1M	2020-03-11 10:37:27	87e77f097f6ebb5127c77662dfc3165e
Miniconda3-py37_4.8.2-MacOSX-x86_64.pkg	61.3M	2020-03-11 10:39:17	43966070a98a8bf590f24d9b44098e11
Miniconda3-py37_4.8.2-MacOSX-x86_64.sh	50.3M	2020-03-11 10:37:45	e0320c20ea13d04407424ecf57b70eaf
Miniconda3-py37_4.8.2-Windows-x86.exe	52.2M	2020-03-11 10:38:51	a3c6c76ab13ff195f2ead63fac87e070
Miniconda3-py37_4.8.2-Windows-x86_64.exe	51.6M	2020-03-11 10:38:26	20d6bd9b3bd62f1fd874315b6b38c159
Miniconda3-py38_4.8.2-Linux-ppc64le.sh	50.5M	2020-03-11 10:39:28	8dbe9589f7ba6e17428ac57658802eb2
Miniconda3-py38_4.8.2-Linux-x86_64.sh	85.7M	2020-03-11 10:39:44	cbda751e713b5a95f187ae70b509403f
Miniconda3-py38_4.8.2-MacOSX-x86_64.pkg	62.3M	2020-03-11 10:40:18	c6f0a7a76bbece0096af55367f926cf7
Miniconda3-py38_4.8.2-MacOSX-x86_64.sh	51.3M	2020-03-11 10:39:58	589972cf83097c97e70c41813f2fe3a2
Miniconda3-py38_4.8.2-Windows-x86_64.exe	52.7M	2020-03-11 10:40:08	da6a97905f458b0fd6ddf3224e6aa60c
Miniconda2-4.7.12.1-Linux-ppc64le.sh	50.9M	2019-10-25 14:32:08	f00e3c5881c2629a9b516cc7a62bbc3c
Miniconda2-4.7.12.1-Linux-x86_64.sh	46.0M	2019-10-25 14:32:08	23bf3acd6aead6e91fb936fc185b033e
Miniconda2-4.7.12.1-MacOSX-x86_64.pkg	47.8M	2019-10-25 14:32:09	a95e15427dad995ab0b373ad00ad6b58
Miniconda2-4.7.12.1-MacOSX-x86_64.sh	39.4M	2019-10-25 14:32:08	5a10de42eb90c1c21dbda191f1ec19b1



在 Docker 平台執行 Anaconda Jupyter!!

有興趣的同學,請參看另一份講義。